

FOUNDATION CONSTRUCTION METHODOLOGY:

- MATERIAL NOTES:

- 1 no. 75mm NAIL INTO TOP (POSITIONED CENTRALLY)
AND 2 No. PERMFIx NAILS INTO SIDE



NOTE: HURRICANE STRAPS REQUIRED FOR TIMBER PURLIN TO RAFTER CONNECTION


WALL TO RAFTER CONNECTION DETAIL



1:10



1:10



2x Y12 BARS T&B
ALL SIDES AT 45° TO
SLAB REBAR

2x Y12 BARS T&B
ALL SIDES PARALLEL
TO SLAB REBAR

TYPICAL REINFORCEMENT DETAIL FOR SLAB OPENINGS

1:20



1:25



1:20



1:20



1:10




1:25

--	--	--

SCIPLINE:

PROVINCE OF THE EASTERN CAPE

IMPLEMENTED BY:	
-----------------	--



SCIPUNE	DWG NO.	STATUS	REVISION	DATE
ENGINEER	HT - 276 - 201	SW	01	14.04.21